


Y11	AC compressor clutch
V35	AC compressor clutch diode
A63	AC control module
S338	AC refrigerant dual pressure switch
S153	AC refrigerant low pressure switch
M7	AC/heater blower motor
S17	AC/heater blower motor switch
S292	AC/heater function control panel
M105	AC/heater recirculation flap motor
31	Battery -
30	Battery +
K46	Engine control (EC) relay
A35	Engine control module (ECM)
M6	Engine coolant blower motor
K12-I	Engine coolant blower motor relay 1 - low speed
K12-II	Engine coolant blower motor relay 2 - high speed
R46	Engine coolant blower motor resistor
B24	Engine coolant temperature (ECT) sensor
F	Fuse
X28-II	Fuse box/relay plate, engine bay 1
X28-I	Fuse box/relay plate, fascia
S3	Headlamp switch
R6	Heater blower speed resistor
K76	Ignition auxiliary circuits relay
15	Ignition switch - ignition ON
K256	Wide open throttle (WOT) relay



AD103232

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

